



15245 Amberly Drive
Tampa, FL 33647
www.cleanearthsystems.com

Toll Free: (800) 282-4293
Fax: (813) 930-2530

LAB-PAK

Closure Instructions

STEP 1: Square up container. Fold in bottom flaps

STEP 2: Tape bottom flaps with 2" wide 3M-Scotch #375 Clear Packing Tape with the tape extending a minimum of 2" over the edges. (Tape in a "H" style pattern)

STEP 3: Insert poly liner bag and stretch around the container interior walls until firmly in place.

STEP 4: Fill the container (bag) with material.

STEP 5: Twist the top of the bag closed tightly to secure the material and seal the bag with a minimum of 6-3/8" cable tie. (zip tie)

STEP 6: Carefully compress the bag of material into the container and fold in top flaps.

STEP 7: Tape top flaps with 2" wide 3M-Scotch #375 Clear Packing Tape with the tape extending a minimum of 2" over the edges. (Tape in a "H" style pattern)
